


# ILLUSTRATION BOOKLET


Part of 595-3271




PICTORIAL 1-1

Model RT-1 Technical


Copyright © 1984  
Heath Company  
All Rights Reserved  
Printed in the United States of America




PICTORIAL 1-2



PICTORIAL 1-3



PICTORIAL 1-4




BLOCK DIAGRAM


## CIRCUIT BOARD X-RAY VIEWS


NOTE: To find the PART NUMBER of a component for the purpose of ordering a replacement part:

- A. Find the circuit component number (U1, C3, etc.) on the "Circuit Board X-Ray View."
- B. Locate this same number in the "Circuit Component Number" column of the "Replacement Parts List."
- C. Adjacent to the circuit component number, you will find the PART NUMBER and DESCRIPTION, which must be supplied when you order a replacement part.



KEYBOARD CIRCUIT BOARD  
(Shown from the component side.)





CPU CIRCUIT BOARD  
(Shown from the component side. The foil  
on the component side is shown in red.)